

Warning: Improper wiring of any electrical device can cause serious injury or death.

These wiring devices should only be installed by a certified electrician or other qualified person.

Caution: This product should be installed in accordance with the National Electrical Code and all applicable local codes and standards.

TURN OFF POWER BEFORE INSTALLING.

1. Attach locknuts on lampholder threads.
2. Using a sealing compound on lampholder threads, install lampholder onto cover.
3. Position lampholder and tighten locknut(s).
4. Pull power supply wires into box, securing with appropriate fitting.
5. Connect ground wire to ground screw on lampholder.
6. Connect hot (black) wires and neutral (white) wires using wire connectors (not included).
7. Close any holes in outlet box according to manufacturer's instructions.
8. Mount lampholder cover to outlet box according to manufacturer's instructions.
9. Install PAR 38 lamp, maximum 150 W (not included).

Advertencia: El cableado incorrecto de cualquier dispositivo eléctrico puede causar lesiones graves o la muerte. Estos dispositivos de cableado solo deben ser instalados por un electricista certificado u otra persona calificada.

Precaución: Este producto debe instalarse de acuerdo con el Código Eléctrico Nacional y todos los códigos y normas locales aplicables.

APAGUE LA ENERGÍA ANTES DE INSTALAR.

1. Fije las contratuercas en el portalámparas de subprocesos.
2. Usando un compuesto sellador de roscas, instale el portalámparas en la cubierta.
3. Colocar el portalámparas y apretar las contratuerca(s).
4. Tire de los cables de alimentación en la caja, asegurandola con el ajuste adecuado.
5. Conecte el cable de tierra al tornillo de tierra del portalámparas.
6. Conectar los cables (negro) caliente y neutro (blanco) usando conectores de cable (no incluidos).
7. Cierre los agujeros en la caja de salida de acuerdo a las instrucciones del fabricante.
8. Montaje de cubierta del portalámparas en la caja de salida de acuerdo con las instrucciones del fabricante.
9. Instale lámpara PAR 38, máximo 150 W (no incluido).